

# TABLE 2: STANDARD MONITORING REQUIREMENTS

Subpart H Water Source Systems Size	Monitoring Periods & Frequency	Total Locations per Monitoring Period	Near Entry Point Locations*:	Average Residence Time	High TTHM Locations	High HAA5 Locations
Less than 500 consecutive	1 during Peak Historical Month	2	1	-	1	-
Less than 500 non-consecutive	1 during Peak Historical Month	2	-	-	1	1
500-3,300 consecutive	4 every 90 days	2	1	-	1	-
500-3,300 non-consecutive	4 every 90 days	2	-	-	1	1
3,301-9,999	4 every 90 days	4	-	1	2	1
10,000-49,000	6 every 60 days	8	1	2	3	2
50,000-249,999	6 every 60 days	16	3	4	5	4
250,000-999,999	6 every 60 days	24	4	6	8	6
1,000,000 - 4,999,999	6 every 60 days	32	6	8	10	8
5,000,000 +	6 every 60 days	40	8	10	12	10

Ground Water Source Systems Size	Monitoring Periods & Frequency of Sampling	Total Locations per Monitoring Period	Near Entry Point Locations*:	Average Residence Time	High TTHM Locations	High HAA5 Locations
Less than 500 consecutive	1 during Peak Historical Month	2	1	-	1	-
Less than 500 non-consecutive	1 during Peak Historical Month	2	-	-	1	1
500-9,999	4 every 90 days	2	-	-	1	1
10,000-99,999	4 every 90 days	6	1	1	2	2
100,000-499,999	4 every 90 days	8	1	1	3	3
500,000 +	4 every 90 days	12	2	2	4	4

\*The EPA says if you have more sites than required, then choose entry points with the highest flows. If you have fewer sites than required, then replace additional sites with TTHM and HAA5 sites.

Blue Earth Labs is a chemical research and development company with a full line of proprietary products specifically engineered to extend the operational life and efficiency of any water infrastructure by removing organic and inorganic contaminants.

For more information, please call: 1.800.259.4456  
Email: [Info@BlueEarthLabs.com](mailto:Info@BlueEarthLabs.com) • Visit: [www.BlueEarthLabs.com](http://www.BlueEarthLabs.com)

